



WR67
UI OVERVIEW



A Comprehensive Guide Through the WR67 User Interface.

HOME (TIME) SCREEN

Next Slide: Menu Options

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF (Maximum ON is 10 Minutes)

View Menu Options



Hold (5 Seconds) Power On/Off

Time_Screen_No_Icons.ai

MENU OPTIONS

Next Slide: Play Golf

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF (Maximum ON is 10 Minutes)

Press: Return to Home (Time)Screen



Press: Scroll Up Through Golf Menu Options
(Scroll order: Play Golf, Settings, Location, Apps, Battery, Tee Time)

Press: Select Option

Press: Scroll Down Through Golf Menu Options
(Scroll order: Play Golf, Tee Time, Battery, Apps, Location, Settings)



PLAY GOLF

Next Slide: Round Info

Shot Distance Feature (Will Function Identically To WR62 Watch)

Toggle Between Golf Menu And FCB Screen

*Golf Menu Includes:

- Battery
- Select Hole (*Note: when this option is selected, it should bring up the current hole)
- Exit Game



Large Back of Green Callout

Toggle between Hazards and FCB Page

Large Front of Green Callout

*No hold function: Cannot Power Off In Play Golf Mode.

FCB.ai



*Note: Backlight is disabled in Play Golf Mode.

ROUND INFO

Next Slide: Battery

When "Exit Game" is selected, a Round Information screen will pop-up and show total time of play and total distance traveled for the round. Press any button to exit the Round Info screen and return to the Home (Time) Screen, or automatically return to the Home (Time) screen after 10 seconds.



FCB.ai



BATTERY

Next Slide: Tee Time

Backlight Control
 -Press: Backlight ON for 10 seconds
 -Hold: Turn Backlight ON/OFF
 (Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



* Note: The watch should be able to connect from this screen. We would like to use the same charging screen as the Neo X firmware (with the scrolling battery icon).

Battery.ai



TEE TIME

Next Slide: Apps

Backlight Control
 -Press: Backlight ON for 10 seconds
 -Hold: Turn Backlight ON/OFF
 (Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Press: Toggle Active Field (Month, Day, Hour, Minute, AM/PM) Up.
 Toggle Flag ON/OFF (With No Fields Active)

1st Press: Activate Day, 2nd Press: Activate Hour, 3rd Press: Activate Minute, 4th Press: Activate AM/PM
 5th Press: Tee Time Set (Flag Icon Will Appear) *Note: Active Fields Will Blink

When Set: Use ▲ To Toggle Tee Time (Flag Icon) ON/OFF (Flag icon appears on Home (Time) screen also.)

Tee Time Will Automatically Enter Play Golf Mode And Acquire GPS Signal 7 minutes Prior To The Set Time, On The Set Day. The User Should Be Able To Set The Tee Time Up To 7 Days In Advance, So This Function Will Need To Work In Accordance With The Current Date

Set_Tee_Time.ai



Home (Time) Screen With Tee Time Set

Press: Return to Home (Time) Screen



* Note: The time area on this screen is dependent upon Time Format setting (12 hour or 24 hour)

Press: Toggle Active Field (Month, Day, Hour, Minute, AM/PM) Down

APPS

Backlight Control

- Press: Backlight ON for 10 seconds
- Hold: Turn Backlight ON/OFF (Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Press: Scroll Up Through Golf Menu Options (Scroll order: Odometer, Timer, Alarm, Stopwatch)

Press: Select Option

Press: Scroll Down Through Golf Menu Options (Scroll order: Odometer, Stopwatch, Alarm, Timer)



Apps_1.ai & Apps_2.ai

Next Slide: Odometer

ODOMETER

Backlight Control

- Press: Backlight ON for 10 seconds
- Hold: Turn Backlight ON/OFF (Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Press ◀ to activate the Odometer. GPS module will power on and search for signal. Upon GPS lock, the odometer timer will begin counting up from zero, and the Distance and Speed fields will begin yielding data based upon the users path.

Press ◀ to pause/restart the Odometer. Press ▲ to reset the Odometer to 0.

Odometer.ai

Next Slide: Stopwatch

STOPWATCH

Next Slide: Alarm

Press to freeze lap time. Stopwatch will continue running in the background. Press again to return to live stopwatch count.

* Note: Backlight will still function when pushing this button.

Press to Start/Pause the stopwatch. When stopwatch is running, "Start" text on screen will read "Pause" (see image below).

Press: Return to Home (Time) Screen



Press when stopped to reset the stopwatch to "000:00 00"



Stopwatch.ai

ALARM

Next Slide: Timer

Toggle Alarm ON/OFF

* Note: Backlight will still function when this button is pressed

Press ◀ key to activate the Alarm Clock in order to set the time.

The 1st press will activate the Hour field, the 2nd press will activate the Minute field. The 3rd press will activate the AM/PM field.

*Note: Active Fields Will Blink
Use ▲ ▼ to adjust time fields, and to toggle between AM/PM in that field. After setting AM/PM, pressing ◀ will set the Alarm, and a bell icon will appear.

Press: Return to Home (Time) Screen



Bell Icon will appear on Home (Time) Screen also, as shown below.



Home (Time) Screen With Alarm Set



* Note: This screen is dependent upon Time Format setting (12 hour or 24 hour)

Alarm.ai

TIMER

Next Slide: Location

Backlight Control

-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Press ◀ key to activate the Timer.

The first press will activate the Hour field, the second press will activate the Minute field.

**Note: Active Fields Will Blink*

Use ▲ ▼ to adjust time fields. After minutes are set, press ◀ to start timer. When timer is running, press ◀ to pause it.

When paused, Press the ▲ key (R) to reset all fields to 0.

Timer.ai



LOCATION

Next Slide: Settings Menu

Backlight Control

-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



The Location screen will show the number of satellites the watch is locked onto, provide HDOP, and provide Lat/Long coordinates.

GPS_Status.ai



SETTINGS MENU

Next Slide: Time-Date

Backlight Control

- Press: Backlight ON for 10 seconds
- Hold: Turn Backlight ON/OFF (Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen

Press: Scroll Up Through Settings Options (Scroll order: Time-Date, Reset, About, Sounds, Odometer, Golf Setup)

Press: Select Option

Press: Scroll Down Through Settings Options (Scroll order: Time-Date, Golf Setup, Odometer, Sounds, About, Reset)



Settings_Menu_1.ai & Settings_Menu_2.ai

TIME-DATE

Next Slide: Set Time

Backlight Control

- Press: Backlight ON for 10 seconds
- Hold: Turn Backlight ON/OFF (Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen

Press: Scroll Up Through Time-Date Options (Scroll order: Time-Date, Format, DST)

Press: Select Option

Press: Scroll Down Through Time-Date Options (Scroll order: Set Time, DST, Format)



Time_Options.ai

SET TIME

Next Slide: Set Time Manually

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Set_Time_Options.ai

Press: Toggle Between By GPS/Manually

Press: Select By GPS or Manually

*Note: When By GPS is Selected, Watch Will Search For GPS Signal. When GPS Lock Occurs, a tone will sound, and The watch will then Return To The Time Screen. Time And Date Will Be Set Automatically By Longitude Position.

See Next Slide For Manually Setting Time.

Press: Toggle Between By GPS/Manually

SET TIME MANUALLY

Next Slide: DST

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Set_Time_Manually.ai

The Set Time Manually option will function the similarly to the WR62 watches. Press ◀ to cycle between Seconds, Minutes, Hours, AM/PM, Day, Month, and Year. Use ▲ ▼ to change the values of the selected field (which will be blinking).

DST

Next Slide: Format

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Press: Toggle Between DST ON: +1/DST OFF: -1

Press: Set Selection And Return To Time Options Menu.

*Note: DST ON Adds 1 hour to Standard time. DST OFF Removes 1 hour from Daylight time (returns to Standard time).

Press: Toggle Between DST ON: +1/DST OFF: -1

DST.ai



FORMAT

Next Slide: Golf Setup

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Press: Toggle Between 12 Hour/24 Hour

Press: Set Selection And Return To Time Options Menu.

Press: Toggle Between 12 Hour/ 24 Hour

Time_Format.ai



* Note: This setting will affect the functionality of the Set Tee Time and Set Alarm screens.

GOLF SETUP

Next Slide: Yds/M

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen

Press: Scroll Up Through Golf Options

Press: Select Option

Press: Scroll Down Through Golf Options



Golf_Options.ai

YDS/M (GOLF SETUP)

Next Slide: Auto-Off

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen

Press: Toggle Between Yards/Meters

Press: Set Selected Option And Return To Golf Setup Menu

Press: Toggle Between Yards/Meters



Yards_Meters.ai

This Selection Sets The Preferred Unit Of Measurement For Play Golf Mode Only; This Selection Does Not Affect The Odometer

AUTO-OFF

Next Slide: Odometer Setting

Backlight Control
 -Press: Backlight ON for 10 seconds
 -Hold: Turn Backlight ON/OFF
 (Maximum ON is 10 Minutes)

Press: Scroll Time Up
 (.5 Hour Increments,
 9.0 Hours Max)



Auto-Off Pop-up message in Play Golf mode



Press: Set Selection And Return To Golf Setup Menu.

 Time Will Scroll Between 2.0 Hours and 9.0 Hours In .5 Hour Increments, And Include A "Disabled" Option.

Press: Scroll Time Down (.5 Hour Increments, 1.5 Hours Minimum)

Press: Return to Home (Time) Screen



Auto-Off.ai

The Auto-Off Feature Will Automatically Exit "Play Golf Mode" And Power The GPS Module Off After The Set Amount Of Time Has Passed (Time Begins Counting Once GPS Lock Is Acquired In Play Golf)
 * Actual Screen TBD

ODOMETER SETTING

Next Slide: Sound Setting

Backlight Control
 -Press: Backlight ON for 10 seconds
 -Hold: Turn Backlight ON/OFF
 (Maximum ON is 10 Minutes)

Press: Toggle Between Miles/Kilometers

Press: Return to Home (Time) Screen



Press: Set Selection And Return To Settings 1 Menu.

Press: Toggle Between Miles/Kilometers



Odometer_Setting.ai

SOUND SETTING

Next Slide: About

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Toggle On/Off

Press: Select On/Off and return to Settings 2 Menu

Press: Toggle Between On/Off

Press: Return to Home (Time) Screen

Sound_Setting.ai

Disabling Key Tones Affects Key Tones Only; Alarm Tones, GPS Acquisition Tones, Etc. Remain Active At All Times

ABOUT SCREEN

Next Slide: Reset

Backlight Control
-Press: Backlight ON for 10 seconds
-Hold: Turn Backlight ON/OFF
(Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen

About.ai

The About screen will show the version of firmware that is installed on the watch.

RESET SCREEN

Backlight Control

- Press: Backlight ON for 10 seconds
- Hold: Turn Backlight ON/OFF (Maximum ON is 10 Minutes)

Press: Return to Home (Time) Screen



Press: Toggle Between Reset/Cancel

Press: Set Selection And Return To the Settings 2 Menu.

Press: Toggle Between Reset/Cancel

System_Reset.ai

Selecting Reset Will Reset Default Settings

